


Chapter 13 – Graphical User Interfaces Part 1

- 13.1 Introduction
- 13.2 Menus
- 13.3 LinkLabels
- 13.4 ListBoxes and CheckedListBoxes
 - 13.4.1 ListBoxes
 - 13.4.2 CheckedListBoxes
- 13.5 ComboBoxes
- 13.6 TreeViews
- 13.7 ListView
- 13.8 Tab Control
- 13.9 Multiple-Document-Interface (MDI) Windows
- 13.10 Visual Inheritance
- 13.11 User-Defined Controls



Menus' terminology




13.1 Introduction

- Continues study of Graphical User Interface
- Explores:
 - Menus
 - **LinkLabels**
 - **ListBox**
 - **CheckedListBox**
 - **ComboBoxes**
 - **TreeView** control
 - Tab controls
 - Multiple-document interface windows



Menus' Visual programming (MenuScript)

4



MainMenu and MenuItem events and properties

Description / Delegate and Event Arguments

MainMenu Properties

| | |
|--------------------|---|
| MenuItem s | Lists the MenuItem s that are contained in the MainMenu . |
| RightToLeft | Causes text to display from right to left. Useful for languages that are read from right to left. |

MenuItem Properties

| | |
|-------------------|--|
| Checked | Indicates whether a menu item is checked (according to property RadioCheck). Default False , meaning that the menu item is not checked. |
| Index | Specifies an item's position in its parent menu. |
| MenuItem s | Lists the submenu items for a particular menu item. |
| MergeOrder | Sets the position of a menu item when its parent menu is merged with another menu. |
| MergeType | Takes a value of the MenuMerge enumeration. Specifies how a parent menu merges with another menu. Possible values are Add , MergeItems , Remove and Replace . |
| RadioCheck | Indicates whether a selected menu item appears as a radio button (black circle) or displays a checkmark. True creates radio button, False displays checkmark; default False . |
| Shortcut | Specifies the shortcut key for the menu item (e.g., <i>Ctrl + F9</i> can be equivalent to clicking a specific item). |



13.2 Menus



| MainMenu and MenuItem events and properties | Description / Delegate and Event Arguments |
|---|--|
| ShowShortcut | Indicates whether a shortcut key is shown beside menu item text. Default is True , which displays the shortcut key. |
| Text | Specifies the text to appear in the menu item. To create an <i>Alt</i> access shortcut, precede a character with & (e.g., & File for File). |
| <i>Common Event</i> | <i>(Delegate EventHandler, event arguments EventArgs)</i> |
| Click | Generated when item is clicked or shortcut key is used. Default when double-clicked in designer. |



```

3  Using System;
4  using System.Drawing;
5  using System.Collections;
6  using System.ComponentModel;
7  using System.Windows.Forms;
8  using System.Data;
9  public class MenuTest : System.Windows.Forms.Form {
12     private System.Windows.Forms.Label displayLabel;
14     private System.Windows.Forms.MainMenu mainMenu;
16     private System.Windows.Forms.MenuItem fileMenuItem;
17     private System.Windows.Forms.MenuItem aboutMenuItem;
18     private System.Windows.Forms.MenuItem exitMenuItem;
20     private System.Windows.Forms.MenuItem formatMenuItem;
22     private System.Windows.Forms.MenuItem colorMenuItem;
23     private System.Windows.Forms.MenuItem blackMenuItem;
24     private System.Windows.Forms.MenuItem blueMenuItem;
25     private System.Windows.Forms.MenuItem redMenuItem;
26     private System.Windows.Forms.MenuItem greenMenuItem;



```



```

28     private System.Windows.Forms.MenuItem timesMenuItem;
29     private System.Windows.Forms.MenuItem courierMenuItem;
30     private System.Windows.Forms.MenuItem comicMenuItem;
31     private System.Windows.Forms.MenuItem boldMenuItem;
32     private System.Windows.Forms.MenuItem italicMenuItem;
33     private System.Windows.Forms.MenuItem fontMenuItem;
34     private System.Windows.Forms.MenuItem separatorMenuItem;
35     [STAThread]
36     static void Main() {
37         Application.Run( new MenuTest() );
38     }
39
40     private void aboutMenuItem_Click(
41         object sender, System.EventArgs e ) {
42         MessageBox.Show("This is an example\nof using menus.",
43             "About", MessageBoxButtons.OK, MessageBoxIcon.Information );
44     }
45
46     private void exitMenuItem_Click(
47         object sender, System.EventArgs e ) {
48         Application.Exit();
49     }
50
51
52
53
54



```




```

28     private System.Windows.Forms.MenuItem timesMenuItem;
29     private System.Windows.Forms.MenuItem courierMenuItem;
30     private System.Windows.Forms.MenuItem comicMenuItem;
31     private System.Windows.Forms.MenuItem boldMenuItem;
32     private System.Windows.Forms.MenuItem italicMenuItem;
33     private System.Windows.Forms.MenuItem fontMenuItem;
34     private System.Windows.Forms.MenuItem separatorMenuItem;
35     [STAThread]
36     static void Main() {
37         Application.Run( new MenuTest() );
38     }
41     private void aboutMenuItem Click(
42         object sender, System.EventArgs e ) {
44         MessageBox.Show("This is an example\nof using menus.",
46             "About", MessageBoxButtons.OK, MessageBoxIcon.Information );
48     }

```




```

50 private void exitMenuItem_Click(
51     object sender, System.EventArgs e ) {
52     Application.Exit();
53 }
54
55 private void ClearColor() {
56     blackMenuItem.Checked = false;
57     blueMenuItem.Checked = false;
58     redMenuItem.Checked = false;
59     greenMenuItem.Checked = false;
60 }
61
62 private void blackMenuItem_Click(
63     object sender, System.EventArgs e ) {
64     ClearColor();
65     displayLabel.ForeColor = Color.Black;
66     blackMenuItem.Checked = true;
67 }

```

User's Function
called by User
program




```
75     private void blueMenuItem_Click(  
76         object sender, System.EventArgs e ) {  
79         ClearColor();  
81         displayLabel.ForeColor = Color.Blue;  
82         blueMenuItem.Checked = true;  
83     }  
85     private void redMenuItem_Click(  
86         object sender, System.EventArgs e ) {  
89         ClearColor();  
91         displayLabel.ForeColor = Color.Red;  
92         redMenuItem.Checked = true;  
93     }  
95     private void greenMenuItem_Click(  
96         object sender, System.EventArgs e ){  
99         ClearColor();  
101        displayLabel.ForeColor = Color.Green;  
102        greenMenuItem.Checked = true;  
103    }
```

```

105 private void ClearFont() {
108     timesMenuItem.Checked = false;
109     courierMenuItem.Checked = false;
110     comicMenuItem.Checked = false;
111 }
113 private void timesMenuItem_Click(
114     object sender, System.EventArgs e ) {
117     ClearFont();
119     timesMenuItem.Checked = true;
120     displayLabel.Font = new Font(
121         "Times New Roman", 14, displayLabel.Font.Style );
122 }
124 private void courierMenuItem_Click(
125     object sender, System.EventArgs e ) {
128     ClearFont();
130     courierMenuItem.Checked = true;
131     displayLabel.Font = new Font(
132         "Courier New", 14, displayLabel.Font.Style );

```






User's Function
called by User
program



```
133     }
134
135     private void comicMenuItem_Click(
136         object sender, System.EventArgs e ) {
137
138         ClearFont();
139
140         comicMenuItem.Checked = true;
141         displayLabel.Font = new Font(
142             "Comic Sans MS", 14, displayLabel.Font.Style );
143     }
144
145     private void boldMenuItem_Click(
146         object sender, System.EventArgs e ) {
147
148         boldMenuItem.Checked = !boldMenuItem.Checked;
149         displayLabel.Font = new Font( displayLabel.Font.FontFamily, 14,
150             displayLabel.Font.Style ^ FontStyle.Bold );
151     }
152
153     private void italicMenuItem_Click(
154         object sender, System.EventArgs e) {
155
156         italicMenuItem.Checked = !italicMenuItem.Checked;
157         displayLabel.Font = new Font( displayLabel.Font.FontFamily, 14,
158             displayLabel.Font.Style ^ FontStyle.Italic );
159     }
160 }
161 }
```




Use the Format menu to change the appearance of this text.



13.3 LinkLabels

- Displays links to other objects
 - Uses **event handlers** to link to right file or program
 - **Start** method of **Process** class opens other programs
- Derived from class **Label**, inherits functionality

LinkLabel
on a form



Hand image displayed
when mouse cursor
over a **LinkLabel**



LinkLabel properties and events

Description / Delegate and Event Arguments

Common Properties

| | |
|-------------------------|---|
| ActiveLinkColor | Specifies the color of the active link when clicked. Default is red. |
| LinkArea | Specifies which portion of text in the LinkLabel is treated as part of the link. |
| LinkBehavior | Specifies the link's behavior, such as how the link appears when the mouse is placed over it. |
| LinkColor | Specifies the original color of all links before they have been visited. Default is blue. |
| Links | Lists the LinkLabel.Link objects, which are the links contained in the LinkLabel . |
| LinkVisited | If True , link appears as if it were visited (its color is changed to that specified by property VisitedLinkColor). Default False . |
| Text | Specifies the text to appear on the control. |
| UseMnemonic | If True , & character in Text property acts as a shortcut (similar to the <i>Alt</i> shortcut in menus). |
| VisitedLinkColor | Specifies the color of visited links. Default is Color.Purple . |

LinkLabel properties and events

Description / Delegate and Event Arguments

Common Event

*(Delegate **LinkLabelLinkClickedEventHandler**, event arguments **LinkLabelLinkClickedEventArgs**)*

LinkClicked



Generated when link is clicked. Default when control is double-clicked in designer.




```
3 using System;
4 using System.Drawing;
5 using System.Collections;
6 using System.ComponentModel;
7 using System.Windows.Forms;
8 using System.Data;
9 public class LinkLabelTest : System.Windows.Forms.Form {
12 private System.Windows.Forms.LinkLabel driveLinkLabel;
13 private System.Windows.Forms.LinkLabel deitelLinkLabel;
14 private System.Windows.Forms.LinkLabel notepadLinkLabel;
15 [STAThread]
16 static void Main() {
18     Application.Run( new LinkLabelTest() );
19 }
21 private void driveLinkLabel_LinkClicked( object sender,
22     System.Windows.Forms.LinkLabelLinkClickedEventArgs e){
24     driveLinkLabel.LinkVisited = true;
25     System.Diagnostics.Process.Start( "C:\\\\" );
26 }
```

LinkLabelTest.cs
Program Output

Click on first
LinkLabel to
look at contents of
C drive



```
28 private void deitelLinkLabel_LinkClicked( object sender,
29     System.Windows.Forms.LinkLabelLinkClickedEventArgs e){
31     deitelLinkLabel.LinkVisited = true;
32     System.Diagnostics.Process.Start(
33         "IExplore", "http://www.deitel.com" );
34 }
```




Click on second **LinkLabel**
to go to the Web Site



```
36 private void notepadLinkLabel_LinkClicked(  
37     object sender,  
38     System.Windows.Forms.LinkLabelLinkClickedEventArgs e) {  
40     notepadLinkLabel.LinkVisited = true;  
43     System.Diagnostics.Process.Start( "notepad" );  
44 }  
45 }
```



Click the third
LinkLabel to
open notepad



13.4 ListBoxes and CheckListBoxes




Fig. 13.8 **Listbox** and **CheckedListBox** on a form.



- **ListBoxes**




- Allow users to view and select from items on a list
- **Static** objects
- **SelectionMode** property determines number of items that can be selected
- Property **Items** returns all objects in list
- Property **SelectedItem** returns current selected item
- Property **SelectedIndex** returns index of selected item
- Property **GetSelected** returns true if property at given index is selected
- Use **Add** method to add to **Items** collection
 - `myListBox.Items.Add("myListItem")`

ListBox properties, methods and events


Description / Delegate and Event Arguments

Common Properties

| | |
|------------------------|--|
| Items | Lists the collection of items within the Listbox . |
| MultiColumn | Indicates whether the Listbox can break a list into multiple columns. Multiple columns are used to make vertical scroll bars unnecessary. |
| SelectedIndex | Returns the index of the currently selected item. If the user selects multiple items, this method arbitrarily returns one of the selected indices; if no items have been selected, the method returns -1 . |
| SelectedIndices | Returns a collection of the indices of all currently selected items. |
| SelectedItem | Returns a reference to the currently selected item (if multiple items are selected, it returns the item with the lowest index number). |
| SelectedItems | Returns a collection of the currently selected item(s). |
| SelectionMode | Determines the number of items that can be selected and the means through which multiple items can be selected. Values None , One , MultiSimple (multiple selection allowed) and MultiExtended (multiple selection allowed via a combination of arrow keys, mouse clicks and <i>Shift</i> and <i>Control</i> buttons). |
| Sorted | Indicates whether items appear in alphabetical order. True causes alphabetization; default is False . |



```
3 using System;
4 using System.Drawing;
5 using System.Collections;
6 using System.ComponentModel;
7 using System.Windows.Forms;
8 using System.Data;
9 public class ListBoxTest : System.Windows.Forms.Form {
12     private System.Windows.Forms.ListBox displayListBox;
14     private System.Windows.Forms.TextBox inputTextBox;
16     private System.Windows.Forms.Button addButton;
17     private System.Windows.Forms.Button removeButton;
18     private System.Windows.Forms.Button clearButton;
19     private System.Windows.Forms.Button exitButton;
20     [STAThread]
21     static void Main() {
23         Application.Run(
24             new ListBoxTest());
25     }
```



```
27 private void addButton_Click(
28     object sender, System.EventArgs e ) {
30     displayListBox.Items.Add( inputTextBox.Text );
31     inputTextBox.Clear();
32 }
34 private void removeButton_Click(
35     object sender, System.EventArgs e ) {
38     if ( displayListBox.SelectedIndex != -1 )
39     {
40         displayListBox.Items.RemoveAt(
41             displayListBox.SelectedIndex );
42     }
43 private void clearButton_Click(
44     object sender, System.EventArgs e ) {
46     displayListBox.Items.Clear();
47 }
49 private void exitButton_Click(
50     object sender, System.EventArgs e ) {
52     Application.Exit();
53 }
54 }
```

Method: `ListBox.ObjectCollection.RemoveAt(Int32)`

Removes the item at the specified index within the collection.

13.4 ListBoxes and CheckedListBoxes

- **CheckedListBoxes**
 - Extends **ListBox** by placing check boxes next to items
 - Can select more than one object at one time



13.4.2 **CheckedListBoxes**

- **CheckedListBox** derives from class **ListBox**
 - Can add to, remove from or clear list
 - Can select multiple items from the list
 - Properties **CurrentValue** and **NewValue** return state of object selected
 - Properties **CheckedItems** and **CheckedIndices** return the objects and indices of selected items respectively



CheckedListBox properties, methods and events

Description / Delegate and Event Arguments

Common Properties

*(All the **ListBox** properties and events are inherited by **CheckedListBox**.)*

CheckedItems

Lists the collection of items that are checked. This is distinct from the selected items, which are highlighted (but not necessarily checked).
Note: There can be at most one selected item at any given time.

CheckedIndices

Returns indices for the items that are checked. Not the same as the selected indices.

SelectionMode

Determines how many items can be checked. Only possible values are **One** (allows multiple checks to be placed) or **None** (does not allow any checks to be placed).

Common Method

GetItemChecked

Takes an index, and returns **True** if corresponding item is checked.

Common Event

*(Delegate **ItemCheckEventHandler**, event arguments **ItemCheckEventArgs**)*

ItemCheck

Generated when an item is checked or unchecked.



CheckedListBox properties, methods and events


Description / Delegate and Event Arguments

ItemCheckEventArgs Properties

| | |
|---------------------|--|
| CurrentValue | Indicates whether current item is checked or unchecked. Possible values are Checked , Unchecked and Indeterminate . |
| Index | Returns index of the item that changed. |
| newValue | Specifies the new state of item. |






```
3 using System;
4 using System.Drawing;
5 using System.Collections;
6 using System.ComponentModel;
7 using System.Windows.Forms;
8 using System.Data;
9 public class CheckedListBoxTest: System.Windows.Forms.Form {
12     private System.Windows.Forms.CheckedListBox
           inputCheckedListBox;
15     private System.Windows.Forms.ListBox displayListBox;
16     [STAThread]
17     static void Main() {
19         Application.Run( new CheckedListBoxTest() );
20     }
```




```




23 private void inputCheckedListBox_ItemCheck(object sender,
        System.Windows.Forms.ItemCheckEventArgs e ){
28     string item=inputCheckedListBox.SelectedItem.ToString();
32     if ( e.NewValue == CheckState.Checked )
33         displayListBox.Items.Add( item );
34     else
35         displayListBox.Items.Remove( item );
36 }
37 }

```



13.5 ComboBoxes

- Combine **TextBox** and drop-down list
- **Add** method adds object to collection
- Properties:
 - **DropDownStyle**: determines type of **ComboBox**
 - **Items**: returns objects in the list
 - **SelectedItem**: returns object selected
 - **SelectedIndex**: returns index of selected item



ComboBox events and properties

Description / Delegate and Event Arguments

Common Properties

| | |
|-------------------------|---|
| DropDownStyle | Determines the type of combo box. Value Simple means that the text portion is editable and the list portion is always visible. Value DropDown (the default) means that the text portion is editable, but the user must click an arrow button to see the list portion. Value DropDownList means that the text portion is not editable and the user must click the arrow button to see the list portion. |
| Items | The collection of items in the ComboBox control. |
| MaxDropDownItems | Specifies the maximum number of items (between 1 and 100) that can display in the drop-down list. If the number of items exceeds the maximum number of items to display, a scroll bar appears. |
| SelectedIndex | Returns index of currently selected item. If there is no currently selected item, -1 is returned. |
| SelectedItem | Returns a reference to the currently selected item. |
| Sorted | Specifies whether items in a list are alphabetized. If True , items appear in alphabetical order. Default is False . |

Common Event

| | |
|-----------------------------|---|
| SelectedIndexChanged | (Delegate EventHandler , event arguments EventArgs) Generated when the selected index changes (such as when a check box has been checked or unchecked). Default when control is double-clicked in designer. |
|-----------------------------|---|

```
3  using System;
4  using System.Drawing;
5  using System.Collections;
6  using System.ComponentModel;
7  using System.Windows.Forms;
8  using System.Data;
9  public class ComboBoxTest : System.Windows.Forms.Form {
12     private System.Windows.Forms.ComboBox imageComboBox;
13     [STAThread]
14     static void Main() {
16         Application.Run( new ComboBoxTest() );
17     }
19     private void imageComboBox_SelectedIndexChanged(
20         object sender, System.EventArgs e ) {
23         Graphics myGraphics = base.CreateGraphics();
25         Pen myPen = new Pen( Color.DarkRed );
27         SolidBrush mySolidBrush =
            new SolidBrush( Color.DarkRed );
```

```
30 myGraphics.Clear( Color.White );
```

```
32 switch ( imageComboBox.SelectedIndex ) {
```

```
34     case 0:
```

```
35         myGraphics.DrawEllipse(myPen, 50, 50, 150, 150 );
```

```
37         break;
```

```
38     case 1:
```

```
38         myGraphics.DrawRectangle(myPen, 50, 50, 150, 150 );
```

```
41         break;
```

```
42     case 2:
```

```
43         myGraphics.DrawEllipse(myPen, 50, 85, 150, 115 );
```

```
45         break;
```

```
46     case 3:
```

```
47         myGraphics.DrawPie(myPen, 50, 50, 150, 150, 0, 45 );
```

```
48         break;
```

```
50     case 4:
```

```
51         myGraphics.FillEllipse(mySolidBrush, 50, 50, 150, 150);
```


```
53         break;
```




```
54     case 5:
```

```
55         myGraphics.FillRectangle(mySolidBrush, 50, 50, 150,
                                     150 );
```

```
57         break;
```

```
58 case 6:  
59     myGraphics.FillEllipse(mySolidBrush, 50, 85, 150, 115 );  
61     break;  
62 case 7:  
63     myGraphics.FillPie(mySolidBrush, 50, 50, 150, 150, 0, 45 );  
65     break;  
66     }  
67 }  
68 }
```





13.6 TreeView





Fig. 13.2


13.6 TreeViews

- Displays nodes hierarchically
- Parent nodes have children
- The first parent node is called the root
- Use Add method to add nodes

Click to expand
node, displaying
child nodes



Click to collapse
node, hiding child
nodes



13.6 TreeView

TreeView properties and events

Description / Delegate and Event Arguments

Common Properties

CheckBoxes Indicates whether checkboxes appear next to nodes. **True** displays checkboxes. Default is **False**.

ImageList Indicates the **ImageList** used to display icons by the nodes. An **ImageList** is a collection that contains a number of **Image** objects.

Nodes Lists the collection of **TreeNode**s in the control. Contains methods **Add** (adds a **TreeNode** object), **Clear** (deletes the entire collection) and **Remove** (deletes a specific node). Removing a parent node deletes all its children.

TreeNode properties and methods

Description / Delegate and Event Arguments

Common Properties

| | |
|---------------------------|---|
| Checked | Indicates whether the TreeNode is checked. (CheckBoxes property must be set to True in parent TreeView .) |
| FirstNode | Specifies the first node in the Nodes collection (i.e., first child in tree). |
| FullPath | Indicates the path of the node, starting at the root of the tree. |
| ImageIndex | Specifies the index of the image to be shown when the node is deselected. |
| LastName | Specifies the last node in the Nodes collection (i.e., last child in tree). |
| NextNode | Next sibling node. |
| Nodes | The collection of TreeNode s contained in the current node (i.e., all the children of the current node). Contains methods Add (adds a TreeNode object), Clear (deletes the entire collection) and Remove (deletes a specific node). Removing a parent node deletes all its children. |
| PrevNode | Indicates the previous sibling node. |
| SelectedImageIndex | Specifies the index of the image to use when the node is selected. |
| Text | Specifies the text to display in the TreeView . |

Common Methods


| | |
|---------------------|-------------------------------------|
| Collapse | Collapses a node. |
| Expand | Expands a node. |
| ExpandAll | Expands all the children of a node. |
| GetNodeCount | Returns the number of child nodes. |

```
3  using System;
4  using System.Drawing;
5  using System.Collections;
6  using System.ComponentModel;
7  using System.Windows.Forms;
8  using System.Data;
9  using System.IO;
10 public class TreeViewDirectoryStructureTest
11     : System.Windows.Forms.Form {
14     private System.Windows.Forms.TreeView directoryTreeView;
15     [STAThread]
16     static void Main() {
18         Application.Run(
19             new TreeViewDirectoryStructureTest() );
20     }
```

```

21 public void PopulateTreeView(
22     string directoryValue, TreeNode parentNode ) {
25     string[] directoryArray =
26         Directory.GetDirectories( directoryValue );
28     try {
30         if ( directoryArray.Length != 0 ) {
35             foreach ( string directory in directoryArray ) {
37                 TreeNode myNode = new TreeNode( directory );
39                 parentNode.Nodes.Add( myNode );
41                 PopulateTreeView( directory, myNode );
42             }
43         }
44     }
46     catch ( UnauthorizedAccessException ) {
48         parentNode.Nodes.Add( "Access denied" );
49     }
50 }

```



```
52     private void TreeViewDirectoryStructureTest_Load(  
53         object sender, System.EventArgs e) {  
57         directoryTreeView.Nodes.Add( "C:\\\\" );  
58         PopulateTreeView("C:\\\\", directoryTreeView.Nodes[0] );  
60     }  
61 }
```

